


MINOLTA

XG-A

OWNER'S MANUAL

E





Your light, compact XG-A is a top-quality single-lens reflex camera whose electronic systems will control exposure for you automatically, which makes taking beautiful pictures as easy as focusing and pressing a button. You can also override the automatic meter setting up to 2 full stops for complete creative control. Electro-magnetic shutter release, unique "touch switch" metering, and an Acute Matte focusing screen making viewing brighter and focusing easier are just a few of the XG-A's many features. Attaching the accessory Auto Winder G enables single/continuous motor film advance up to 2 frames-per-second. Minolta's X-series Auto Electroflashes electronically switch the XG-A's shutter over for strobe exposures when charged and signal flash-ready in the finder; the 320X and 200X also enable continuous-sequence flash with the winder. Besides Minolta MD lenses, your XG-A is compatible with virtually all Minolta interchangeable lenses made to date and all applicable Minolta SLR system accessories.

Before using your camera for the first time, study this manual all the way through. In this way, you can take good photos and realize the full potential of your XG-A right from the start. Be sure to keep this manual for later reference.

CONTENTS

MAIN FEATURES	4	EXPOSURE-CONTROL	
NAMES OF PARTS	6	FUNDAMENTALS	21
SUMMARY OF OPERATION	8	METERING WITH THE XG-A	22
STRAP AND CASE	10	VIEWFINDER	23
ATTACHING AND REMOVING		AUTOMATIC EXPOSURE CONTROL ...	24
LENSES	11	Automatic operation	24
BATTERIES AND POWER	12	Eyepiece cap	25
Installing batteries	12	WAYS OF USING AUTO MODE	26
Battery holder	13	General use	26
Testing batteries	13	Creative aperture control	27
Main switch	14	Creative shutter control	28
Touch switch/operating button	14	AUTOMATIC-EXPOSURE	
Cold-weather operation	15	ADJUSTMENT	29
LOADING AND ADVANCING FILM	15	WHEN AND HOW MUCH TO ADJUST	
Film-advance lever and frame counter ...	19	EXPOSURE	30
FILM SPEED	20	"B" SETTING	33
Setting film speed	20	HOLDING THE CAMERA	34
(ASA/DIN conversion scale)	20		

FOCUSING	35
Depth of field	36
Depth-of-field scale	36
Infrared index	37
RELEASING THE SHUTTER	38
SELF-TIMER	40
REWINDING AND UNLOADING	
FILM	41
FLASH PHOTOGRAPHY	43
Synchronization	43
Connecting flash units	43
USING OTHER THAN MD OR	
MC LENSES	44
Auto Rokkor lenses	44
RF (mirror-type) and manual-preset lenses	44

XG-A SYSTEM ACCESSORIES	45
Auto Winder G	46
X-series Auto Electroflashes	47
Remote Cord S and L	48
Wireless Controller IR-1 Set	49
CAMERA SPECIFICATIONS	50
CARE AND STORAGE	52

MAIN FEATURES

Fail-safe electronic exposure system

Incorporating many of the features developed for Minolta's top electronic cameras, the XG-A covers a wide range of photographic conditions. Its electronic shutter which automatically locks to prevent overexposure and electromagnetic shutter release with unique touch switch metering add to the handling ease of the camera.

XG-A's system features:

- Full automatic exposure by stepless shutter speeds from 1/1000 to 1 sec.
- Electromagnetic shutter release.
- Unique "Touch switch" metering.
- Shutter-release lock prevents overexposure when light is over meter's range or battery power is low.
- Piezoelectric audible signals for low shutter-speed settings and self-timer operation.

Solid-state information viewfinder

- Special focusing screen has split-image and microprism focusing aids, plus scientifically

developed new type of matte field that is up to 50% brighter than conventional matte screens.

- Automatic shutter-speeds, indicated by LED's, are visible in viewfinder.
- LED at "60" position blinks as flash-ready signal when X-series Auto Electroflashes are attached and charged.

Easy handling controls

Lightweight and compact, the X-7 is human engineered to fit the user's hands for smooth operation:

- Smooth short stroke film advance.
- Large, easy-to-adjust shutter-function dial.
- "Soft-touch" electromagnetic shutter release.
- Curve formed body with cushioned body grip.
- Minolta bayonet lens mount with large release button.
- Balanced winder operation.

Quick attach auto winder

The XG-A's accessory auto winder attaches quickly without access caps to remove or store, freeing the user from advancing film in single-frame or continuous operation up to two frames per second. Its strong, efficient coreless micromotor winds as many as 150 or more cartridges per set or charge of batteries. At the end of each cartridge the motor automatically shuts off.

Special dedicated flash units


When attached to the XG-A and ready to fire, the X-series Auto Electroflashes start a flash-ready signal blinking in the viewfinder and automatically set the shutter for X-synchronization (1/60 sec.) when the shutter is released. Other individual features include thyristor circuitry for winder synchronization and maximum battery life, tiltable head for bounce flash, filters for special effects, multiple aperture settings and full manual operation. From the compact and economical 118X to the 320X with its exclusive Variable Guide-Number/


Power Control, there is an X-series flash to meet any need.

User oriented features

- Up to two stops' continuous adjustment over or under the normal electronic setting.
 - X-type flash synchronization through the hot shoe.
 - Electronic self-timer with blinking indicator light.
 - Eyepiece cap for unmanned or similar operation.
 - Exclusive Safe Load Signal monitors film alignment and advance.
 - Release terminal for tripod shots with electronic or standard release cord.
 - Shutter not operative when operation switch off.
 - Virtually all existing Minolta interchangeable lenses and applicable system accessories can be used.
- operation.

NAMES OF PARTS







SUMMARY OF OPERATION

The steps pictured on this page outline use of your X6-A on automatic mode. They give a general idea of how very easy it is to get


perfectly exposed pictures with this camera and are keyed to corresponding sections of the manual for ready reference. This brief guide




1. Check batteries (see p. 12).



2. Move main switch to "ON" (p. 13).



3. Open back cover (p. 14).



7. Set selector dial to "AUTO" (p. 24).




8. Set lens aperture (p. 24).




9. Adjust focus (p. 35).

may also be useful for good results after you have not used the camera for some time. It is not, however, a substitute for the detailed


instructions in the rest of this manual, which should be thoroughly studied for best results.




4. Load film properly; close cover (p. 15).




5. Advance film to "1" (p. 16).



6. Set film speed (p. 18).



10. Release shutter (p. 38).








11. Turn power off (p. 13).



12. Rewind and remove film (p. 41).

STRAP AND CASE


The strap (provided with camera) and case (sold separately) should be attached as shown to keep your camera handy from use and to protect it from being dropped or bumped.



ATTACHING AND REMOVING LENSES

To Attach

1. Remove the body cap from the camera lens mount and the rear cap from the lens bayonet, each by turning the cap counterclockwise.
2. Align the red mounting index on the lens barrel with the red index above the camera lens mount; insert the lens bayonet into the mount; and turn the lens clockwise until it locks into place with a click.



To Remove

While pushing the lens-release button, turn the lens counterclockwise as far as it will go; then lift the lens bayonet out of the mount.

CAUTION

If it becomes necessary to set the lens down without a rear lens cap attached, be sure to set the lens only on its front end (except for fisheye lenses) as damage to the diaphragm control pin could result from rear lens contact with a hard surface.



BATTERIES AND POWER

Two 1.5v alkaline-manganese (Eveready A-76 or equivalent) or 1.55v silver-oxide (Eveready EPX-76/S-76 or equivalent) batteries supply the power for the meter, electronic exposure control, electromagnetic release, electronic shutter settings, and LED indication.

CAUTION


- The shutter will not release when the operating button is pushed if: battery power is too low; the operating switch is at "OFF;" exposure conditions exceed the range of the automatic exposure system.
- Do not use 1.35v mercury batteries (Eveready EPX-675 or equivalent), which have a similar shape.

NOTE

- If the camera is not be used for more than two weeks, it is advisable to remove the batteries.
- Fresh spare batteries may be stored in the battery holder provided with the camera strap.


Installing batteries

1. Using a coin or similar object, turn the battery-chamber cover counterclockwise and remove it.
2. After wiping terminals with a clean dry cloth and handling only by the edges, insert two of the specified batteries plus (+) side out into the sleeve on the inside of the cover. (If batteries are inserted improperly, they will not make contact, and no current will flow.)
3. Replace the cover and screw it in clockwise as far as it will go.



Battery holder

A holder for carrying spare batteries is provided with this camera strap. To install batteries, follow the steps illustrated. Slide the holder off the strap to remove batteries.




Testing batteries

Move the main switch to align the index with "B.C." If the red battery-check indicator on the front of the camera lights, batteries are serviceable. When released, the main switch will automatically move to the "ON" position.

Test batteries immediately after installing them. If the indicator does not light, make sure that they are fresh and have been inserted correctly.


Batteries should be tested from time to time thereafter, preferably before starting each new roll of film and particularly before starting picture-taking sessions or trips.



Main switch


To operate the camera, move the main switch to "ON." This allows current to flow to the touch switch/operating button. The main switch also serves as the self-timer and battery check switch.

To prevent accidental exposures and needless battery drain, always be sure to move the main switch to "OFF" when not using the camera.



Touch switch/operating button

Finger contact with the touch switch/operating button activates the camera's electronic shutter and, when the shutter-function selector is set at "AUTO", powers the electronic exposure control and LED circuits. If proper contact with the touch switch is not possible (i.e., while wearing gloves or when fingers are dry), slight pressure on the button will also activate the camera.



NOTE

Wipe off any dust or dirt that might accumulate on the touch switch with a clean dry cloth (make sure main switch is turned off first). This will insure good contact and proper operation.


Cold-weather operation

Batteries by nature tend to lose power as temperatures drop. While alkaline-manganese batteries will meet all requirements under normal conditions, for heavy sustained cold-weather operation (approx. -10°C) it is recommended that silver-oxide type batteries be used.


Regardless of battery type used, remember to always use fresh batteries and keep a spare set with you when using your camera in cold weather.

After you have not used your camera for some time, check the Safe Load Signal and to be sure that there is no film in the camera. If the camera is unloaded, proceed as follows:


1. Pull up on the back-cover release knob until the camera back springs open.






2. Leaving the knob pulled out, position a film cartridge in the chamber with the projecting-spool end toward the bottom of the camera. Then push the back-cover release knob all the way in, rotating it slightly to do so if necessary, and pull out enough film leader to just reach the take-up spool.




3. Insert the end of the film leader as shown into one of the slots in the take-up spool so that the tooth is engaged with a sprocket hole near the end of the leader. Make sure that the end of the leader does not project from another slot between tabs on the spool.




4. Operate the film-advance lever slowly until the film has begun to wind firmly around the take-up spool, the sprocket teeth are engaged with holes on both edges of the film, and the slack in the film is taken up. If the advance lever stops at the end of a full stroke during this procedure, release the shutter and continue.



5. After making sure the film is taut, close the camera back and push in on it until it clicks locked.
6. A red "S" should now appear opposite the index in the frame-counter window. Advance film and release the shutter until the index points to "1" on the frame-counter dial.



7. A red bar should also now appear at the extreme left in the Safe Load Signal window. This indicates that the film is loaded and winding properly on the take-up spool. If the Safe Load Signal does not appear or swings far to the right in the window, repeat steps 1 through 6 to assure that film is properly engaged on the spool. As you continue to take pictures, the red signal will move gradually toward the right in the window, indicating that film is advancing properly.




CAUTION

Film should be handled and loading done in subdued light — at least shaded from direct sunlight by the body.


Film-advance lever and frame counter

The film-advance lever is designed with 30° unengaged movement before the beginning of its engaged stroke to allow swinging it out from the body so that the right thumb will fit comfortably behind it. Continuing to move the lever until it stops, an angle of 130° , advances film and frame counter and cocks the shutter for the next exposure.



When the lever stops and resists further movement at the end of a film, never attempt to force it farther. (See p. 41 for instructions on rewinding and unloading film.)

The counter automatically resets for film loading when the camera back is opened.




FILM SPEED


Each film on the market has an ASA or DIN exposure-index number to indicate its sensitivity to light. For correct exposure, the meter must be set for the effective exposure index of the film in use.

Setting film speed

To do this, lift up on the knurled ring of the shutter-function selector and turn it until the proper ASA indication appears centered in the film-speed window and locks in that position when the ring is released. Marks between numbered graduations indicate ASA numbers as



shown in the ASA/DIN conversion scale at right.



ASA	DIN	ASA	DIN
25	• 15	250	• 25
32	• 16	320	• 26
40	• 17	400	• 27
50	• 18	500	• 28
64	• 19	640	• 29
80	• 20	800	• 30
100	• 21	1000	• 31
125	• 22	1250	• 32
160	• 23	1600	• 33
200	• 24		

EXPOSURE-CONTROL FUNDAMENTALS

The two camera exposure-control settings are lens opening (aperture) and shutter speed. The size of the aperture determines the amount or volume of light reaching the film from a given subject and lighting. The shutter speed determines the length of time this light acts upon the film. Apertures are expressed in f-numbers, which are larger for small openings and vice versa (e.g., $f/16$ represents a small opening, $f/2$ a large one). Shutter speeds are expressed in seconds or fractions thereof, which are generally the reciprocals of the numbers shown on shutter-speed scales (e.g. $60 = 1/60$ sec., and $2 = 1/2$ sec.). At usual apertures, each f-number setting (e.g., $f/8$) lets in twice as much light as the next numerically larger one ($f/11$) and half as much as the next smaller ($f/5.6$). Similarly, each shutter speed (e.g., $1/60$ sec.) allows light to strike the film twice as long as

the next higher speed ($1/125$) and half as long as the next lower one ($1/30$). The interval between two standard f-numbers (say, $f/4$ and $f/5.6$) or shutter speeds (say, $1/15$ and $1/30$) is one "stop." Total exposure on the film is determined by the combination of aperture and speed. Other things being equal, using the next smaller f-number (i.e., giving one stop more exposure) will balance using the next higher shutter speed (i.e., giving one stop less exposure), and so on. A great range of combinations (e.g., $f/5.6$ at $1/30$, $f/4$ at $1/60$, $f/2.8$ at $1/125$, $f/2$ at $1/250$, etc.) will thus yield the same total exposure. The specific combination you choose under given lighting conditions will depend upon the degree to which you want the greater depth of field (see p. 36) of smaller apertures or the greater movement-blur preventing ability of faster speeds (p. 28).

METERING WITH THE XG-A

The center-weighted metering system in your XG-A employs two CdS cells mounted behind the pentaprism so that light from all parts of the viewfield (picture area) is measured but influence from a broad central area is greatest. Thus the reading should yield satisfactory exposure without adjustment as long as the main subject area occupies a major part of the frame.

If the subject area to be measured occupies a relatively small part of the frame, move the camera so that the main subject fills most of the frame. Note the shutter-speed setting in this position and compensate for the exposure difference with the shutter-function selector when making the exposure from the original position. Further, if the most important area is very much brighter or darker than the rest of the frame and does not fill most of it, exposure should be decreased or increased with the same

control from 1/2 to 2 stops, the exact amount varying with the specific brightness difference and the effect desired. (p. 29).

As with most metering systems, strong sources of direct light or other very bright areas may influence the reading adversely if allowed to dominate the frame.


Though your XG-A finder is designed to minimize the effect on the meter of light entering through the finder eyepiece under usual conditions, care must be exercised to prevent this especially if you wear glasses. Use of a rubber eyecup is further recommended when the subject is in shade and the camera is in sunlight, when bright sidelight falls between eye and eyepiece, or when stop-down metering is used, particularly at small apertures (see p. 44). When viewing is unnecessary, the eyepiece cap (see p. 25) can be used to completely eliminate this problem.

VIEWFINDER

As you look through the viewfinder of your XG-A, you can see:

- ① Split-image/microprism focusing spot
- ② Shutter speed scale
- ③ Indicator LED's (Show shutter speed being set on auto mode; LED at "60" also blinks as flash-ready signal with X-series Auto Electroflashes)
- ④ LED over- or under-range indicators


For operation details, see the following sections on exposure control and focusing.



AUTOMATIC-EXPOSURE CONTROL

Automatic operation

1. Turn the shutter-function selector to align "AUTO" with the index, at which point it is locked to prevent accidental movement.
2. Set the desired lens opening by turning the aperture ring on the lens barrel. The shutter speed as indicated by lighted LED at the



- right of the frame will vary automatically to yield proper exposure for the aperture and other settings with the light being metered.
3. It is then only necessary to confirm focus (see p. 35), compose your picture, and release the shutter (p. 38).



4. The XG-A's accurate range of shutter operation on automatic mode is 1/1000 to 1 sec., as indicated by the shutter-speed scale. When the over-range indicator lights, the shutter will lock to prevent overexposure. Lighting of the under-range LED indicates use of a shutter speed longer than one second. For either, the aperture or other conditions should be adjusted so that an LED lights within the scale's range.


NOTES

- When the over-range indicator lights, be sure not to depress the operating button while adjusting the aperture or other conditions. This will cause the shutter to release at the instant the exposure is within metering range and result in an unwanted picture.
- To continuously provide more or less exposure on automatic mode, see p. 29.
- New Minolta MD lenses have a minimum aperture lock for use with X-700 or XD cameras. This lock should be released when using your XG-A camera.

Eyepiece cap

For remote or unmanned operation or when the camera is set on a support and used without viewing on automatic mode, be sure to attach the eyepiece cap as shown. This will prevent unwanted light from entering through the eyepiece and affecting the meter reading and exposure when the eyepiece is not being shielded by the photographer's head, as it normally would be.

The eyepiece cap has a slot that allows threading it on the camera strap to avoid loss and keep it handy for use.



WAYS OF USING AUTO MODE

On AUTO mode, your XG-A will set the precise shutter speed for proper exposure for you automatically. Even so, you have considerable control over results and can adjust aperture and shutter speed over considerable ranges to suit the conditions and yourself.

General use

For usual good personal pictures with a minimum of care where no particular effect is desired, simply set the aperture as indicated in the table. These guide settings will provide as much depth of field (see p. 36) as possible while producing a shutter speed fast enough to stop most subject motion and guard against blur from camera movement (see p. 38).

Guide to setting aperture

	Sunny	Hazy Sun	Heavy Over-cast	Indoors
ASA 25	f/8	f/4	f/2	f/1.4
ASA 80	f/11	f/5.6	f/4	f/1.4
ASA 100	f/11	f/5.6	f/4	f/1.4
ASA 200	f/11	f/8	f/5.6	f/2
ASA 400	f/16	f/11	f/8	f/2.8

(These are only guidelines for typical picture taking situations. For additional information see page 20.)

NOTE

Use of a steady support (p. 39) or an electronic flash (p. 43) is recommended for use with shutter speeds of 1/60 or slower.

Creative aperture control

There may be times when it will be most important to set the lens aperture to obtain a particular effect, such as rendering a certain range in sharp focus or emphasizing a subject against an out-of-focus background. In this case, set the desired aperture, and let the

camera select the shutter speed. Small f-numbers yield a shallow field of sharp focus, as in photo A below, while large f-numbers give greater depth of field, as in photo B. To determine actual depth of field, use the depth-of-field scale (see p. 36).

A: Large lens opening



B: Small lens opening



Creative shutter control

At other times, the subject or effect you want may make the shutter speed more important. In this case, turn the aperture ring until the lighted LED indicates the required speed on the finder scale; exposure will automatically be correct. Fast shutter speeds such as 1/500 to 1/1000 sec. can "freeze" fast action, as in


C: Fast shutter speed



photo C below. Such slow speeds as below 1/30 sec. can be used to emphasize subject flow or motion, as in photo D.

No matter how the camera is used, it is important to support it (see p. 34) and release the shutter properly (p. 38).

D: Slow shutter speed






AUTOMATIC-EXPOSURE ADJUSTMENT

To deliberately increase or decrease exposure from the normal value in automatic mode, press the auto-setting release and set the shutter-function selector at the desired position between “-2” and “+2”. Set minus (-) numbers to darken exposure and plus (+) numbers to lighten exposure, as indicated in the table.

The shutter-function selector locks at the normal automatic setting (“AUTO”) and has click stops at each half-stop setting. Intermediate positions between click stops can also be used.

NOTES

- Always return the shutter-function selector to “AUTO” after using exposure-adjustment settings.
- The XG-A’s automatic exposure system will not operate if the shutter-function selector is set outside the ± 2 stops range.



WHEN AND HOW MUCH TO ADJUST EXPOSURE

1. In situations where there is a great contrast difference between the subject and background and the most important area is considerably darker than the area surrounding it, set the shutter-function selector at from $+1/2$ to $+2$. Examples of such pictures are ones with strong backlighting and no fill-in illumination, such as photos A and B,

or subjects against a background of snow or light-colored sand, unless the bright area occupies a very small part of the image frame.

2. If the most important subject area is much brighter than the rest of the picture, set the shutter-function selector at from -1 to -2 .

A: Without adjustment




B: Exposure increased



Examples of this kind of picture are subjects in a spotlight or shaft of sunlight, or against a very dark background, as photos C and D, unless the background occupies only a small area in the image frame.

3. As above, when copying documents printed on white stock or on other materials that are predominantly light in color, an adjustment to $+1/2$ or more may be called for.

C: Without adjustment



Similarly, you will probably want to make an adjustment from -1 to -2 for predominantly dark copy meter or that on a dark background.

4. The above suggestions will serve as starting points for trial; individual conditions and taste will of course determine what exposure you choose.

D: Exposure decreased







"B" SETTING

Turning the shutter-function selector to align "B" with the index (while depressing the auto-setting release if from "AUTO" setting) sets the camera for making "bulb" exposures. That is, the shutter will open when the operating button is depressed and remain open until it is released.

NOTE

When a standard cable release is used with the XG-A and "B" setting, be sure not to let any metal part of the release touch any metal part of the camera body while the shutter is open, as this will cause the shutter to close and end the exposure.




HOLDING THE CAMERA

Holding the camera securely when exposures are made is as important as focusing. Even slight movement at the instant of exposure can result in "blurred" photographs, especially when operating with slow shutter speeds. A recommendable way that permits ready operation of important controls is shown here.

To hold the camera horizontally, cradle the bottom of it in the palm of your left hand with the thumb and index or middle finger on the focusing ring of the lens. These fingers can also be used to turn the aperture ring. Grasp the camera body firmly with the right hand as

shown so that the index finger rests on the operating button. In this position, the thumb can conveniently operate the film-advance lever!

The camera may be held in a vertical position as shown (center) using the thumb of the right hand to push the shutter release while the left hand is used for support and focusing. Another possibility is to rotate the camera from the horizontal position and hold it so that the rewind-crank end is cradled in the left hand as shown.




FOCUSING

The focusing screen of your XG-A features a split-image spot surrounded by a band of microprisms in the center of an Acute Matte field.

To focus the camera visually with usual lenses, look through the viewfinder and turn the focusing collar on the lens until the upper and lower subject images in the spot are exactly aligned with no broken lines between them and/or the subject image in the band does not shimmer or appear broken up. At this point, the subject image within the focusing aid should appear clearest and seem to blend with that on the matte field around it.

Out of focus



Though the most satisfactory focusing aid and method depend upon the conditions and personal preference of the photographer, the above method may provide the best results with medium wideangle to short telephoto lenses.

Generally speaking, however, you will probably find that using the split-image spot will provide the easiest way to focus with subjects having vertical lines; the microprism band for lenses from medium wideangle through medium telephoto, especially with subjects not having vertical lines; and the matte field for longer lenses or macro or other work involving considerable lens extension.


Subject in focus



Depth of field

The distance behind and in front of the focused distance within which the image appears acceptable sharp is called the depth of field.

It extends a greater distance behind the focused distance than in front and is determined by three factors: the aperture size, the distance at which the lens is focused, and the focal length of the lens in use. Depth of field




increases as the lens is stopped down (e.g., $f/2$ to $f/16$) and becomes greater the farther from the camera the lens is focused. It decreases as the lens is opened up (e.g. $f/16$ to $f/2$) and the closer to the camera the lens is focused. Depth of field is greater for short focal length lenses than for telephotos at the same focused distance and aperture. It is at its least for any given lens in normal mounting when the lens is at maximum aperture (as when metering and focusing normally with Minolta MD- or MC-type lenses) and at minimum focusing distance.

Depth-of-field scale

The near and far limits of acceptable sharpness can be determined from the depth-of-field scale on the lens barrel. With the lens focused at a given point, the image will be in satisfactory focus from the nearer value to the farther value on the distance scale indicated by the depth-of-field scale marks for the aperture to be used.


For example, if a 50mm lens is focused at

5m (about 16 ft.) and the aperture is f/8, the appropriate graduations to left and right of the index on the depth-of-field scale indicate acceptable sharpness from about 3.4m to 9.7m (approx. 11 to 32 ft.).



Infrared index

For proper focus when taking pictures with infrared radiation, first focus your subject with visible light as described above, then attach a red filter and turn the focusing ring to the right to align the point of proper focus on the distance scale with the index designated with a small red dot (earlier MD lenses have an "R" instead of a dot) in the depth-of-field scale. Set exposure according to the film manufacturer's recommendations.



RELEASING THE SHUTTER

The way the camera is supported (see p. 34) when exposures are made and how the shutter is released are as important as focusing for best photographic results, and to avoid blurred pictures due to camera movement during exposure these factors become more critical the slower the shutter speed.


You may wish to use the figure "60" on the shutter-speed scale as the reference point to gauge the chance of camera movement. When the LED lights below it, you should pay special attention to both camera and subject movement in taking pictures.

With the possible exception of fastest speeds, the camera or hands holding it should generally be firmly steadied against your face or body when you release the shutter.

At slower speeds, it is advisable to steady the camera against a doorframe, post, or other firm support while depressing the release.

The shutter should always be released with a slow, steady squeeze — never a quick jab — preferable while holding your breath.

DANGER OF BLUR FROM CAMERA/SUBJECT MOVEMENT




For maximum sharpness when making exposures too long to permit hand-holding the camera, mount it on a tripod using the built-in socket on the bottom and release the shutter with a Minolta electronic Remote Cord or a standard cable release screwed into the



threaded socket provided on the side of the lens mount.

If the eyepiece is not being shielded by the photographer's head when the shutter is released in this way, the eyepiece cap should be used (see p. 25).



SELF-TIMER

The electronic self-timer built into your XG-A can be used to delay release of the shutter for about 10 seconds after actuation.

To operate it:

1. Advance the film, compose your picture, and focus.
2. With the shutter-function selector at a setting other than "B," move the main switch to align the index with "SELF-TIMER."
3. Depress the operating button. The blinking light on the front of the camera will indicate the delay has been started. Approximately 2.5 sec. before the exposure is made, the



LED indicator will speed up to signal the end of the delay. You may cancel the self-timer by moving the main switch to "OFF."


NOTE

- After using the self-timer be sure to move the main switch off the "SELF-TIMER" setting.
- In automatic mode, the self-timer will cancel if exposure conditions exceed the upper range of the metering system. Operation will resume when aperture or other conditions are adjusted so that exposure conditions are within metering range.



REWINDING AND UNLOADING FILM


1. Push the rewind button.



2. Unfold the rewind crank and turn it in the direction indicated by the arrow on it until the red Safe Load Signal bar moves out of the window to the left. You will then feel tension on the film increase and disappear, and the crank will turn freely.



3. When you are certain that the film is completely rewound, pull out the back-cover release knob to open the back and remove the cartridge.



Synchronization

When a Minolta X-series Auto Electroflash is being used on the XG-A with the camera's shutter-function selector set at any position other than "B," the "60" LED in the finder will blink as a flash-ready signal and the shutter will be automatically switched over to 1/60 sec. for proper X sync. If you are using an electronic flash other than an X-series Auto Electroflash, the shutter-function selector must be set at "X" to assure proper coverage of the film frame.

Electronic flash ("strobe")	1 through 1/60, B
Class M or MF flashbulbs	1 through 1/15, B
Class FP flashbulbs	1 through 1/15, B

NOTE

As indicated by the table, 1/60 is the maximum shutter speed for proper X synchronization. Slower speeds can also be used under certain conditions if desired for particular

effects. Be sure not to use speeds faster than 1/60, (i.e. 1/125 and upward) with electronic or auto-flash units.

Connecting flash units

Cordless clip-on flash units such as the Auto Electroflash 200X and 132X are attached and electrically connected by simply sliding them into the camera's hot shoe.



USING OTHER THAN MD OR MC LENSES

Metering and exposure with Auto Rokkor lenses having built-in preview buttons, RF Minolta (reflex-mirror type), and manual-preset Minolta lenses are by the stop-down method as follows:

Auto Rokkor lenses

1. After focusing, depress the lens' preview button to stop down the aperture.
2. With the shutter-function selector set at "AUTO", select an aperture as explained on pages 24 and 25. The viewfinder field will darken as the lens is stopped down, and the split-image spot and microprism band may become unusable due to darkening.
3. With the lens stopped down to the proper taking aperture, release the shutter.

RF (mirror-type) and manual-preset lenses

Proceed as for Auto Rokkors above, except that use of a stop-down button is not necessary as metering and exposure are always made at taking aperture.

NOTE

Because they have neither meter coupling nor preview buttons, Minolta 35mm f/2.8 CA Shift lens, Auto Bellows I, and some Auto Rokkor lenses can not be used with the XG-A or auto mode.

XG-A SYSTEM ACCESSORIES




Auto Winder G




The Auto Winder G is an automatic film winder that helps the photographer focus full attention on the creative aspects of photography by removing the interruption of having to wind the film after each picture. Attaching is quick and easy with no access caps to remove or store. Just a light touch of the shutter release is all that is required to take either successive or single frames with the winder automatically advancing the film after each one. The winder drive mechanism stops automatically at the end of each cartridge, and film can be easily rewound with the winder attached.

All of these features combine with the XG-A to help you capture the fast paced action of a sports car race or the fleeting expressions of a child at play.




X-series Auto Electroflashes



To make taking flash pictures as simple and easy as it is to take normal shots with your XG-A, Minolta offers four automatic electronic flashes designed especially for your camera.

All of the four X-series Auto Electroflashes feature dedicated-flash functions that electronically set the camera for proper X-sync and activate a blinking flash-ready signal in the viewfinder when the flash is charged and ready to fire.

This and other individual features make the Auto Electroflash line-up the most comprehensive offered by any camera manufacturer.



Thyristor circuitry for winder synchronization and maximum battery life (200X and 320X), bounce flash (132X and 320X), filters for special effects (132X and 320X), multiple auto-aperture settings and manual mode (all models), and Ni-Cd battery power supply (all models) are just a few of the features available to you in the X-series line.

From the compact and economical 118X to the 320X with its complete accessory flash system and exclusive Variable Guide Number/Power Control, there is an X-series flash to meet any need.

Remote Cord S and L

These cords are designed for operating the XG-A from a distance. Each screws into the shutter release socket on the side of the lens mount. The Cord S is 50cm (about 20 in.) long, while the Cord L is 5m (16-1/2 ft.). These cords facilitate shots mounted on a tripod or remote wildlife pictures. In combination with the Auto Winder G, the Cord L can be used to make single or continuous sequence exposures at the subject position, from a remote location, etc.



Wireless Controller IR-1 Set

The IR-1 set is designed for remote control operation of certain Minolta SLRs and 8mm cine cameras. The Receiver senses infrared rays emitted from the Transmitter and transfers a release signal to the camera. This permits remote control of a camera at a distance of up to 60 meters (nearly 200 feet).

With a single Transmitter unit, any number of cameras can be operated simultaneously or independently in up to three individual groups.



SPECIFICATIONS

- Type: 35mm single-lens reflex with automatic aperture-priority exposure control
- Lens mount: Minolta SLR bayonet, 54° rotating angle; coupling for full-aperture metering and automatic diaphragm control with Minolta MD and MC lenses
- Auto-exposure control: Special low-voltage, low-current computer circuit, actuated by contact or pressure on "touch switch" operating button, varies the shutter speed continuously and steplessly to yield proper exposure according to metering system indication at the aperture, film speed, and exposure adjustment set. Auto-exposure range: EV 2 to EV 17 (e.g., 1/2 sec. at f/1.4 to 1/1000 at f/11) at ASA 100 with f/1.4 lens
- Shutter: Horizontal-traverse focal-plane type; electronically controlled speeds: 1/1000 to 1 sec., steplessly on automatic mode
- Metering: Full-aperture TTL center-weighted averaging type, by two CdS cells mounted on either side of the eyepiece at the rear of the pentaprism
- Film-speed range: ASA 25 to 1600 set on the shutter-function selector
- Auto-exposure adjustment: Up to ±2 EV continuous adjustment of automatic exposure with 1/2 EV click-stops and lock at "AUTO" (zero setting)
- Mirror: Oversize quick-return type
- Viewfinder: Eye-level fixed pentaprism type showing 93% of 24 x 36mm film-frame area
- Magnification: 0.87X with 50mm standard lens focused at infinity; Acute Matte focusing screen with central horizontally oriented split-image focusing spot surrounded by microprism band; stepless speeds indicated by 7 light-emitting diodes; LED over-/under-range indicators; LED at "60" position also blinks as flash-ready signal with the X-series Auto Electro-flashes

Flash sync: Hot shoe for X sync (disconnects when unit not installed): Electronic flash synchronizes at 1/60 sec.

Extra contact on hot shoe receives signal from camera-control contact of the X-series Auto Electroflashes

Film advance: Motorized: Through built-in coupler key with accessory Auto Winder G

Manual: By lever with single 130° stroke after 30° unengaged movement

Film-advance release button for rewinding; advancing-type frame counter and Safe Load Signal that indicates film loading and advancing conditions

Power: Two 1.5v alkaline-manganese (Eveready A-76 or equivalent) or 1.55v silver-oxide (Eveready EPX-76/S-76 or equivalent) cells contained in camera base power both auto exposure control and shutter's electronically governed operation.

LED battery check-indicator lights when operating switch in battery check position

Shutter will not release when voltage too low for proper operation

Self-timer: Electronic, LED indicated types; approximately 10 sec. delay

Other: 4-slot take-up spool.

Size and weight: 52 x 88 x 138mm (2 x 3-7/16 x 5-5/8 in.)

485g (17-1/8 oz.) without lens and power cells

Accessories: Exclusive Auto Winder G, Auto Electroflash 320X, 200X, 132X and 118X, Wireless Controller IR-1, Remote Cord S 50cm (20-in.) and Remote Cord L 5m (16-ft.); MD, MC and other interchangeable Minolta lenses and applicable Minolta SLR system accessories

Specifications subject to change without notice

CARE AND STORAGE

- As with all high-precision instruments, no part of your XG-A should ever be forced at any time. If operation is not as you think it should be, carefully restudy the applicable instructions or consult an authorized Minolta service representative.
- Always keep your camera in its case with the lens capped when not in use.
- Never subject your camera to shock, high heat and/or humidity, water, or harmful chemicals or gases.
- Never lubricate any part of the body or lens.
- Always use a body cap when a lens is not installed on the body. Keep lenses, properly capped front and rear, in their cases when not in use.
- Never touch the shutter curtains or anything inside the front of the body with the fingers. These parts and the inside of the back should be dusted with a soft brush from time to time as necessary, with particular care never to exert pressure on the shutter curtains.
- Never touch lens or other glass surfaces with the fingers. If necessary, remove loose matter from them with a blower lens brush. Use special photographic lens tissue or a soft clean cloth to remove smudges or fingerprints with a gentle circular motion. Only if absolutely necessary, the tissue may be moistened very slightly with not more than one drop of a satisfactory quick-evaporating fluid cleaner specially compounded for photographic lenses. Such fluids must never be dropped directly on the glass surface.
- Smudges or fingerprints on the mirror may be removed with lens tissue slightly moistened with lens-cleaning fluid as above.
- External camera and lens-barrel — but not glass — surfaces may be wiped with a soft, silicone-treated cloth.
- Never leave the shutter cocked when the camera is to be stored overnight or longer. It is advisable to operate the film advance and release the shutter once or twice from time to time during extended storage.

- If the camera is not to be used for more than two weeks, the batteries should be removed.
- If the camera is to be stored for a long period of time, body and lens should be returned to their original packing and kept

in a cool, dry place away from dust or chemicals, preferably in an airtight container with a drying agent such as silica gel.

Minolta Camera Co., Ltd.

Minolta Camera Handelsgesellschaft m.b.H.

Minolta France S.A.

Minolta (UK) Ltd.

Minolta Vertriebsgesellschaft m.b.H.

Minolta Nederland B.V.

Minolta (Schweiz) GmbH

Minolta Svenska AB

Minolta Corporation

Head Office

Los Angeles Branch

Chicago Branch

Atlanta Branch

Minolta Canada Inc.

Head Office

Montreal Branch

Vancouver Branch

Minolta Hong Kong Limited

Minolta Singapore (Pte) Ltd.

30, 2-Chome, Azuchi-Machi, Higashi-Ku, Osaka 541, Japan

Kurt-Fischer-Strasse 50, D-2070 Ahrensburg, West Germany

357 bis, rue d'Estienne d'Orves, 92700 Colombes, France

1-3 Tanners Drive, Blakelands, Milton Keynes, Buckinghamshire MK14 5EW, England

Seidengasse 19, A-1072 Wien, Austria

Zonnebaan 39, Postbox 264, 3600 AG, Maarssenbroek-Maarssen, The Netherlands

Riedhof V, Riedstrasse 6, 8953 Dietikon-Zürich, Switzerland

Brännkyrkagatan 64, Box 17074, S-Stockholm 17, Sweden

101 Williams Drive, Ramsey, New Jersey 07446, U.S.A.

3105 Lomita Boulevard, Torrance, CA 90505 U.S.A.

3000 Tollview Drive, Rolling Meadows, IL 60008, U.S.A.

5904 Peachtree Corners East, Norcross, GA 30071, U.S.A.

1344 Fewster Drive, Mississauga, Ontario L4W 1A4, Canada

7575 Trans Canada Hwy., Montreal Quebec H4T 1V6, Canada

1620 W. 6th Avenue, Vancouver, B.C. V6J 1R3, Canada

Oriental Centre Ground Floor, 67-71 Chatham Road South, Kowloon, Hong Kong

5th Floor, Chiat Hong Bldg., 110, Middle Road, Singapore 0718

CLEANING AND STORAGE

in a cool, dry place away from dust or chemicals, preferably in an airtight container with a drying agent such as silica gel. It must be stored in a container that should be carefully resealed after use. Refer to the instructions or consult an authorized Minolta service representative.

- Always keep the camera in a protective case when not in use.
- Never use harsh chemicals or abrasives to clean the camera.
- Never use a brush or compressed air to clean the camera.
- Always use a body cap when the camera is not in use.



MINOLTA